


# View Net Trunk Cable


The View Net Trunk Cable is the backbone of the View Smart Building Network, providing both power and communications to multiple network terminals through a single cable. The Trunk Cable is available in both pre-terminated and un-terminated configurations.

The Trunk Cable is terminated with a male BNC connector, and it is designed to fit with the female BNC connectors in the View Net Control Panels and Trunk Cable Splitters.


#### **Pre-terminated Assembly**



#### Field Terminated Assembly



## **Application Example**



### **Ordering Information**

Ordering Part Number	Description
VN-TC-TXX	10 AWG Coax Trunk Cable. Pre-terminated with BNC male connectors. (Replace 'XX' with corresponding length code)
VN-TCP-TXX	Plenum-rated 10 AWG Coax Trunk Cable. Pre-terminated with BNC male connectors. (Replace 'XX' with corresponding length code)
VN-TC-UYY	10 AWG Coax Trunk Cable. Unterminated. (Replace 'YY' with corresponding length code)
VN-TCP-UYY	Plenum-rated 10 AWG Coax Trunk Cable. Unterminated. (Replace 'YY' with corresponding length code)
VN-BNC-TC	BNC Male Connector for Trunk Cable (fits LMR-400 Coax)

## Length Chart for Pre-Terminated Cables

Length Chart			
xx	Length (Feet)	Length (m)	
O1	1	0.3	
05	5	1.5	
06	6	1.8	

# Length Chart for Unterminated Cables

Length Chart				
YY	Length (Feet)	Length (m)		
05	500	154.2		
10	1000	304.8		

# Specifications

Max Current	3 A
Max Voltage	300 V
Bend Radius	1.00 in
Cable Rating	Plenum rated option available
Warranty	All cables and components carry a warranty for a period of 5 years from date of delivery by View. Refer to standard warranty terms and conditions for more details.
Rated Temperature	Plenum: -20°C to 75°C Non-Plenum: -20°C to 80°C
Used in Conjunction with	View Net Trunk Cable Splitter View Net Control Panel View Net Network Window Controller View Net Drop Cable
Routing locations	Above ceiling grids, within interstitials, within spandrel locations, within drywall spaces and within framing channels.

#### **Requirements for Cold Weather Installation**

If the cable has to be installed when the temperature is below 32°F, the following precautions should be taken to ensure that the jacket does not crack:

- Store the cable in a heated area with temperatures above 60°F for 24 hours before installation.
- Cables need to be handled with care and not dropped, kinked, or bent roughly.
- Pull cables slowly, use large sheaves and lubes suitable for cold temperatures.